

Windowmate™

WINDOWS & DOORS

Caring for your uPVC Windows & Doors

uPVC windows and doors need very little maintenance, however to ensure that your windows and doors retain their pristine appearance you should bear the following tips in mind.

Cleaning

Slightly dirty frames can be cleaned with warm water and washing up liquid. Extremely dirty frames should be cleaned with special cleaning fluid (available from any Windowmate branch).

Avoid using abrasive cleaners and dry cleaning with a duster. Cleaning solutions and polishes that contain solvents or thinners should not be used as they will damage the frames and seals.

Ventilation

Double glazed windows are designed to close very tightly and conserve energy and will, under normal circumstances, prevent condensation. However, where humidity levels are high condensation may occur on cold surfaces, this can easily be solved with correct ventilation.

Windows should be opened sufficiently on a daily basis to allow the moist air out and fresh air in. Your new windows will also be fitted with trickle vents which aid ventilation.

Handles and Hinges

All moving parts of fittings should be lightly oiled once or twice a year to ensure that your uPVC windows will always open smoothly.

Repairs and Service

If, over time, your uPVC windows and doors need attention, contact us -

Tel: 028 6772 1148



REHAU

**Authorised
Partner**